Original		Rechange	
	Power		Power
	Up / P+		Up
	Up / P+		CH+ / Page+
	Menu		Menu / Home
	Left		Left
	Right		Right
	Down / P-		Down
	Down / P-		CH- / Page-
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Rechange	
	- -		Guide / EPG / -/--
0	0	0	0
	P < P		Fav / Marker / PC
	PP		Back / Return
	Vol +		Vol +
	I-II		Audio / Lang I/II
	Mute		Mute / Dimmer
	Vol -		Vol -
	Info		Info / Angle
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	[TV]	SHIFT + 1	Shift + 1
	[TV]		TV/Radio /
	[AV]		AV / Input / RDS
	[≡]		Text / Goto

Original		Rechange	
	[≡◷]		Subtitle / EQ
	[/ ≡]		Picture / Format
	[≡X]		Exit / Cancel / Clear
	[≡↕]		Zoom / Size
	[≡?]		Display / Media
	[≡i]		Smart / List

Original	Rechange

Original		Rechange	
	Power		Power
	Up / P+		Up
	Up / P+	CH	CH+ / Page+
	Menu	HOME MENU	Menu / Home
	Left		Left
	Select	OK	OK
	Right		Right
	Down / P-	CH PAGE	CH- / Page-
	Down / P-		Down
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8

Original		Rechange	
9	9	BLUETOOTH 9	9
+10 --	+10	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
REPEAT P<P	Repeat	APP REPEAT	Green / APP / Repeat
SEARCH PP	Search	NETFLIX SEARCH	Red / Netflix / Search
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
DISPLAY INFO	Display	MEDIA DISPLAY	Display / Media
AUDIO/LIST	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
PROG/FAV	Prog	PROGRAM TV/ RADIO	TV/Radio /
C TV	C	Prime Video RANDOM	Blue / Prime Video / Random
ANGLE AV	Angle	ANGLE INFO	Info / Angle
RETURN	Return	RETURN BACK	Back / Return
TIME	Time	TIMER SLEEP	Sleep / Timer
◀◀	◀◀	TUNE- ◀◀	<< / Tune-
▶▶	▶▶	TUNE+ ▶▶	>> / Tune+

Original	Rechange	Original	Rechange
⏮	PRESET- ⏮ I << / Preset-		
⏭	PRESET+ ⏭ >>I / Preset+		
⏯	SLOW ▶ Play / Slow		
⏯	STEP-FREEZE ⏸ Pause / Step / Freeze		
■	HOLD ■ Stop / Hold		
Title	TITLE SOUND Sound / Title		
Open / Close	SURROUND ⏏ Eject / Surround		

Original	Rechange	Original	Rechange
On/Off	Power	Menu Right	Right
Mute	Mute / Dimmer	Menu Down	Down
Txt Stop	Stop / Hold	Back	Back / Return
Tone+	>> / Tune+	Volume+	Vol +
Lang	Sound / Title	Chan. Up	CH+ / Page+
Menu audio	Audio / Lang I/II	Volume-	Vol -
Subt. List	Subtitle / EQ	Display	Display / Media
Txt Expand	Zoom / Size	Chan. Down	CH- / Page-
Sleep Timer	Sleep / Timer	1	1
Return TV	TV/Radio /	2	2
Menu video	D. Menu / Top	3	3
Text	Text / Goto	4	4
Menu	Menu / Home	5	5
Menu Up	Up	6	6
Info	Info / Angle	7	7
Menu Left	Left	8	8
OK Enter	OK	9	9

Original	Rechange	Original	Rechange
Guide -/-- 1.	Guide / EPG / -/--		
0/10	0		
2. Fav P/C 2.	Fav / Marker / PC		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Lang	+ Shift + Audio / Lang I/II		