Original		Rechange	
	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
DIMMER	Dimmer	DISC NAV LIST	List
A	Speakers A	A	Red
B	Speakers B	B	Green
COAXIAL	Coaxial	1	1
OPTICAL	Optical	2	2
NET	Net	3	3
LINE 1	Line 1	4	4
LINE 2	Line 2	5	5
LINE 3	Line 3	6	6
MODE	Mode	PICTURE FORMAT	Format
TUNER	Tuner	7	7
CD	CD	8	8
FM	FM	SEARCH TV/R	TV/R
TUNING	<< Tuning	«	<<
TUNING	Tuning >>	»	>>

Original		Rechange	
AM	AM	APP MEDIA	Media
PRESET	< Preset	CH –	Ch -
PRESET	Preset >	+ CH	Ch +
POP-UP MENU	Pop-Up Menu	TOP MENU MENU	Menu
HOME	Home	HOME SMART	Smart
NOW PLAYING	NDW Playing	D	Blue
	Up	▲	Up
	Down	▼	Down
	Right	▶	Right
	Left	◀	Left
ENTER	Enter	OK	Ok
SETUP	Setup	E-MANUAL D.MENU	D. Menu
RETURN	Return	RETURN BACK	Back
VOLUME	Volume+	+ VOL	Vol +
VOLUME	Volume-	VOL –	Vol -
MUTE	Mute	MUTE	Mute
	Stop	■	Stop

Original		Rechange		Original	Rechange
	Pause		Pause		
	Play	PLAY MODE	Play		
	I<<		I<<		
OPTION	Option	SETTINGS OPT	Options		
	>>I		>>I		
DISPLAY	Display	DISPLAY INFO	Info		
REPEAT	Repeat	REPEAT TEXT	Text		
SHUFFLE	Shuffle	TIMER AV	AV		