

VISIOSAT
TDT
TVT300

Mandis Shop S.L.
Av. Cerdanyola Nº 75 1º Of. 115 - Sant Cugat del Vallès (Barcelona)
info@mandis.es



Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
	Power		P/Ch +	P+	
MUTE	Mute		P/Ch -	P-	
1	1		VOL +	Vol+	
2 ABC	2		VOL -	Vol-	
3 DEF	3			Up	
4 GHI	4			Down	
5 JKL	5		OK	OK	
6 MNO	6			Left	
7 PQRS	7			Right	
8 TUV	8		MENU	Menu	
9 WXYZ	9		EXIT RETURN	Exit	
0/10	0		TOP MENU	Lang	
1. GUIDE			PICT TITLE		
2. FAV			EPG	EPG	
AUTO/TRK					
SUBT	Subt.				
AV Dvd/Tv			ZOOM		
TEXT	Text			Info	
TV	TV/♪		RED	Red/F1	
BACK	Back		GREEN	Green/F2	
			YELLOW	Yellow/F3	
			BLUE	Blue/F4	