







































































































Original	Replacement	Original	Replacement
 Power	 Power	 TShift	 Eject
 Mute	 Mute	 Freeze	 3D
 DTV	 Media	 Rec	 Rec
 Rec List	 List	 Red	 Red
 TXT	 Text	 Green	 Green
 Sleep	 Sleep	 Yellow	 Yellow
 1	 1	 Blue	 Blue
 2	 2	 Info	 Info
 3	 3	 Source	 AV
 4	 4	 Up	 Up
 5	 5	 Right	 Right
 6	 6	 Down	 Down
 7	 7	 Left	 Left
 8	 8	 Enter	 Ok
 9	 9	 Menu	 Menu
 0	 0	 Exit	 Exit
 Back	 Back	 Vol+	 Vol +





Original		Replacement		Original		Replacement	
	Vol-		Vol -		-/--	 + 	Shift + Guide
	Guide		Guide		P.Mode	 + 	Shift + Format
	FAV		Pre Ch		S.Mode	 + 	Shift + Dual
	CH+		Ch +				
	CH-		Ch -				
	Hold / Play-Pause		Play				
	Pause		Pause				
	Reveal / <<		<<				
	Size / >>		>>				
	Index / Stop		D. Menu				
	Stop		Stop				
	I<<		I<<				
	Subpage / >>		>>				
	Format		Format				
	Audio		Dual				
	Subt		Subt				
	TV/Radio		TV/R				

