





































| Original   | Replacement   |
|--|---|
|  Power  |  Power                       |
|  Red    |  Red / Netflix / Search      |
|  Green  |  Green / APP / Repeat        |
|  Yellow |  Yellow / YouTube / Repeat   |
|  Blue   |  Blue / Prime Video / Random |
|  Menu   |  Menu / Home                 |
|  P<P    |  Smart / List                |
|  Up     |  Up                          |
|  Left   |  Left                        |
|  Ok     |  OK                          |
|  Right |  Right                      |
|  Down |  Down                      |
|  AV   |  AV / Input / RDS          |
|  Tv/R |  TV/Radio /                |
|  Info |  Info / Angle              |
|  I-II |  Audio / Lang I/II         |
|  Vol+ |  Vol+                      |

| Original   | Replacement   |
|--|---|
|  P+     |  CH+ / Page+                 |
|  Vol-   |  Vol-                        |
|  Mute   |  Mute / Dimmer               |
|  P-     |  CH- / Page-                 |
|  1      |  1                           |
|  2      |  2                           |
|  3      |  3                           |
|  4      |  4                           |
|  5      |  5                           |
|  6      |  6                           |
|  7     |  7                          |
|  8    |  8                         |
|  9    |  9                         |
|  PP   |  Back / Return             |
|  0    |  0                         |
|  Exit |  Exit / Cancel / Clear     |
|  Exit |  Shift + Guide / EPG / -/- |





| Original      | Replacement        |
|---------------|--------------------|
| [≡]/Text      | Text / Goto        |
| [≡o]          | << / Tune-         |
| [≡+]          | >> / Tune+         |
| [≡x]          | << / Preset-       |
| [.≡]/[*]      | >>  / Preset+      |
| [≡♦]/[+]/Wide | Picture / Format   |
| [≡?]/PC       | Fav / Marker / PC  |
| [≡i]/Guide    | Guide / EPG / -/-- |
|               |                    |
|               |                    |
|               |                    |
|               |                    |
|               |                    |
|               |                    |
|               |                    |
|               |                    |
|               |                    |
|               |                    |
|               |                    |
|               |                    |
|               |                    |
|               |                    |
|               |                    |

| Original | Replacement |
|----------|-------------|
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |

