



























































































Original	Replacement	Original	Replacement
 Standby	 Power	 Vol-	 Vol -
 Input	 AV	 CH+	 Ch +
 Tv	 TV/R	 CH-	 Ch -
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 Enter	 Ok
 6	 6	 Q.Menu/3D	 Menu
 7	 7	 Home Smart Tv	 Eject
 8	 8	 Premium Smart	 Dual
 9	 9	 Back	 Back
 0	 0	 Exit	 Exit
 Mute	 Mute	 Sleep	 Sleep
 Q.View	 Options	 AV Mode	 Media
 -/List	 Guide	 Energy/Saving	 List
 Vol+	 Vol +	 FAV/Mark	 Text





Original		Replacement		Original	Replacement
	3D		3D		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	Line Tv		Shift + Options		
	Info		Info		
	Ratio		Format		
	Widgets		D. Menu		
	Simplink		Subt		
	My Apps		Shift + Back		
	Play		Play		
	Pause		Pause		
	Stop		Stop		
	Rec		Rec		
	>>		>>		
	<<		<<		

