




















































Original	Replacement
	 Power
	 AV
	 Menu
	 D. Menu
	 TV/R
	 Guide
	 Smart
	 Text
	 Ok
	 Up
	 Down
	 Left
	 Right
	 Red
	 Green
	 Yellow
	 Blue

Original	Replacement
	 Eject
	 Back
	 Options
	 Play
	 Stop
	 Pause
	 <<
	 >>
	 I<<
	 >>I
	 Vol +
	 Vol -
	 Mute
	 1
	 2
	 3
	 4





Original		Replacement		Original		Replacement	
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Subtitle		Subt				
	Audio		Dual				

