










































































Original	Replacement	Original	Replacement
	Standby		Power
	STB PWR		Shift + Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/Quick Access		0
	List		List
	AD		Subt
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Mute		Mute
	Micro/Q		Format
	Home/Recents		TV/R
	*		Menu
	Back/Exit		Back
	Guide		Guide
	Mouse Up		>>
	Mouse Down		<<
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Netflix		Shift + Media
	Amazon		Media
	Source		AV





Original	Replacement	Original	Replacement
 Text	 Text		
 T.Opt/Magic Link	 Options		
 Info	 Info		
 Play	 Play		
 Pause	 Pause		
 Live	 3D		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

