



































































Original		Replacement		Original		Replacement	
	Power		Power		Timer		AV
	Mute		Mute		BBS		Subt
	Function		Menu		Mem./CLK-ADJ		Back
	Band		TV/R		Repeat		Text
	Intro		Ok		Ran		Media
	Stop		Stop		1		1
	Play		Play		2		2
	Pause		Pause		3		3
	I<</HR./Tun Dn		I<<		4		4
	Tun		>>I		5		5
	Vol+		Vol +		6		6
	Vol-		Vol -		7		7
	EQ Mode		Dual		8		8
	Find/Mo/St		Options		9		9
	Mem/Dir-Up		Up		+0/+00		0
	Mem/Dir-Dn		Down				
	Sleep		Sleep				

