





Original		Replacement		Original		Replacement	
	Power		Power		Title/TTX		Text
	Open/Close		Eject		Mute		Mute
	1		1		Info		Info
	2		2		Vol-		Vol -
	3		3		Vol+		Vol +
	4		4		Play		Play
	5		5		Pause		Pause
	6		6		Stop		Stop
	7		7		Setup		Options
	8		8		Source		AV
	9		9		Tv/Radio		TV/R
	0		0		Return		Back
	10+		Shift + Guide		Enter		Ok
	EPG		Guide		Up		Up
	Goto		Smart		CH+		Ch +
	Favorite		Pre Ch		CH-		Ch -
	Menu		Menu		Down		Down





	Original	Replacement	Original	Replacement
	 Right	 Right	 Blue/Slow	 Blue
	 Left	 Left		
	 <<	 <<		
	 >>	 >>		
	  <<	  <<		
	 >>	 >>		
	 Subtitle	 Subt		
	 Zoom	 Shift + Eject		
	 Language	 Dual		
	 PBC	 Format		
	 Program	 Sleep		
	 L/R	 Exit		
	 Video	 Shift + Smart		
	 P/N	 Media		
	 Red/Repeat	 Red		
	 Green/A-B	 Green		
	 Yellow/Angle	 Yellow		

