






































































| Original | Replacement |
|---|--|
|  |  Mute / Dimmer |
|  |  Power |
|  |  1 |
|  |  2 |
|  |  3 |
|  |  4 |
|  |  5 |
|  |  6 |
|  |  7 |
|  |  8 |
|  |  9 |
|  |  Setup / OPT / |
|  |  0 |
|  |  AV / Input / RDS |
|  |  Shift + 1 |
|  |  Sound / Title |
|  |  Picture / Format |

| Original | Replacement |
|---|---|
|  |  Info / Angle |
|  |  Up |
|  |  Left |
|  |  OK |
|  |  Right |
|  |  Down |
|  |  Red / Netflix / Search |
|  |  Green / APP / Repeat |
|  |  Yellow / YouTube / Repeat |
|  |  Blue / Prime Video / Random |
|  |  Vol+ |
|  |  Text / Goto |
|  |  Menu / Home |
|  |  CH+ / Page+ |
|  |  Vol- |
|  |  Back / Return |
|  |  TV/Radio / |





| Original | Replacement | Original | Replacement |
|----------|-------------------------|----------|-------------|
| | CH- / Page- | | |
| | Fav / Marker / PC | | |
| | Subtitle / EQ | | |
| | Audio / Lang I/II | | |
| | Guide / EPG / -/-- | | |
| | + Shift + Info / Angle | | |
| | + Shift + 5 | | |
| | + Shift + 4 | | |
| | + Shift + 3 | | |
| | + Shift + 2 | | |
| | D.Menu / Top | | |
| | Zoom / Size | | |
| | Eject / Surround | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement | Original | Replacement |
|----------|-------------|----------|-------------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

