




































































Original		Replacement		Original		Replacement	
	Power		Power		Up		Up
	[≡i]/Info		Info		Down		Down
	Mute		Mute		Right		Right
	1		1		Left		Left
	2		2		Enter		Ok
	3		3		Index		Media
	4		4		List		List
	5		5		CH+		Ch +
	6		6		CH-		Ch -
	7		7		Vol+		Vol +
	8		8		Vol-		Vol -
	9		9		♥		Pre Ch
	0		0		Sleep		Sleep
	[≡?]/Source		AV		EPG		Guide
	(O/I/II/Audio		Dual		Recall		Back
	Menu		Menu		Red		Red
	Exit		Exit		<<		<<





	Original	Replacement	Original	Replacement
	Green	B Green		
	Yellow	C Yellow		
	I<<	I<<		
	>>I	>>I		
	Blue	D Blue		
	[=]	Text		
	Play	Play		
	Pause	Pause		
	Stop/Still	Stop		
	[=+]	Format		
	Radio	TV/R		
	[=◆]/[+]	3D		
	[=x]	Options		
	[=O]/Subtitle	Subt		
	DMP	Smart		
	Rec	Rec		

