Mandis shop

Samsung AH5902733B

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | Power | | Power | | |
| | Source | | AV | | |
| | Vol + | | Vol + | | |
| | Vol - | | Vol - | | |
| | Back | | Back | | |
| | Mute | | Mute | | |
| | Play | | Play | | |
| | Pause | | Pause | | |
| | I<< | | I<< | | |
| | >>I | | >>I | | |
| | Sound | | Dual | | |
| | Sound Effect | | Options | | |
| | Bluetooth | | Subt | | |
| | Sound Control | | Ok | | |
| | < | | Left | | |
| | > | | Right | | |
| | | | | | |

https://telecomandi.si/en/Samsung-AH59-02733B-replacement-remote-control-for-Samsung-AH59-02733B.htm