



Original	Replacement	Original	Replacement
 Power	 Power	 Up	 Up
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Red	 Red
 6	 6	 Green	 Green
 7	 7	 Yellow	 Yellow
 8	 8	 Blue	 Blue
 9	 9	 Exit	 Exit
 0	 0	 Mute	 Mute
 Menu	 Menu	 Source	 AV
 TV	 TV/R	 Audio	 Dual
 Vol +	 Vol +	 Info	 Info
 Vol -	 Vol -	 Subtitle	 Subt
 P +	 Ch +	 Size	 Format
 P -	 Ch -	 Presets	 Pre Ch



