



Original	Replacement	Original	Replacement
	Power		Power
	Audio In		Red
	USB		Green
	Coax		Yellow
	AUX		Blue
	OPT		Options
	Repeat		Text
	Play		Play
	Pause		Pause
	>		>>
	I<		I<<
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Audio Sync+		Ch +
	Audio Sync-		Ch -
	Bass+		Up
			Bass-
			Treble+
			Treble-
			Surr
			Night
			Down
			Right
			Left
			Smart
			Media

