






































Original	Replacement	Original	Replacement
	Power		Power
	Stop		Stop
	Pause		Pause
	Rec		Rec
	<<		Info
	>>		Options
	>>		Back
	[<>]		Multiview
	Search		Up
	*		Down
	Tv Guide		Right
	List		Left
	Sources		Netflix
	Smart Tv		Media
	Home		Ok
	Exit/tv		Vol +
	Red		Vol -
			Mute
			Ch +





Original	Replacement	Original	Replacement
CH-	Ch -		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
Subtitle	Subt		
Text	Text		

Original	Replacement	Original	Replacement

