





































































Original		Replacement		Original		Replacement	
	Power		Power		Vol+		Vol +
	Pause		Pause		Vol-		Vol -
	Rec		Rec		◆+		Ch +
	Stop		Stop		◆-		Ch -
	>>		>>		Clear		Exit
	<<		<<		Enter		Smart
	Play		Play		*		Guide
	>		>>		#		Pre Ch
	<		<<		0		0
	i		Info		Red		Red
	Mute		Mute		Green		Green
	Windows		Media		Yellow		Yellow
	←		Back		Blue		Blue
	Up		Up		1		1
	Down		Down		2		2
	Right		Right		3		3
	Left		Left		4		4





Original		Replacement		Original		Replacement	
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	[O]		Options				
	[:=]		Dual				
	[>]		Subt				
	[·]		TV/R				
	[T]		Menu				
	OK		Ok				

