







































































Original	Replacement
 Power	 Power
 Source	 AV / Input / RDS
 HDMI	 Shift + 0
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 TTX/MIX	 Text / Goto
 0	 0
 PRE-CH	 Fav / Marker / PC
 Vol+	 Vol+
 Mute	 Mute / Dimmer

Original	Replacement
 P+	 CH+ / Page+
 Vol-	 Vol-
 CH List	 Shift + Smart / List
 P-	 CH- / Page-
 Smart Hub	 Smart / List
 Menu	 Menu / Home
 Guide	 Guide / EPG / -/--
 Tools	 Setup / OPT /
 Up	 Up
 Info	 Info / Angle
 Left	 Left
 Enter	 OK
 Right	 Right
 Return	 Back / Return
 Down	 Down
 Exit	 Exit / Cancel / Clear
 Red/A	 Red / Netflix / Search





Original		Replacement		Original	Replacement
	Green/B		Green / APP / Repeat		
	Yellow/C		Yellow / YouTube / Repeat		
	Blue/D		Blue / Prime Video / Random		
	Social/Tv		TV/Radio /		
	Search	 +  + 	Shift + Red / Netflix /		
	3D		Picture / Format		
	E-Manual		D.Menu / Top		
	P.Size		Zoom / Size		
	AD/Subt.		Subtitle / EQ		
	<</l<<		<< / Tune-		
	Pause		Pause / Step / Freeze		
	>>/>>l		>> / Tune+		
	Rec		Rec / Rec Mode		
	Play		Play / Slow		
	Stop		Stop / Hold		

