
































































Original		Replacement		Original		Replacement	
	Power		Power		EPG		Guide
	Mute		Mute		Sat		Smart
	1		1		Exit		Exit
	2		2		Up		Up
	3		3		Prog +		Ch +
	4		4		Down		Down
	5		5		Prog -		Ch -
	6		6		Right		Right
	7		7		Vol +		Vol +
	8		8		Left		Left
	9		9		Vol -		Vol -
	0		0		Ok		Ok
	Pause		Pause		TV / Radio		TV/R
	Recall		Back		Zoom		Eject
	Fav		Pre Ch		Page -		<<
	Menu		Menu		Page -		I<<
	i		Info		Help		D. Menu





Original		Replacement		Original	Replacement
	F1		Options		
	Page +		>>		
	Page +		>>		
	UHF		Format		
	P/N		3D		
	TV/SAT		Media		
	Subtitles		Subt		
	Audio		Dual		
	Red / Audio		Red		
	Green / Mosaic		Green		
	Yellow / Clock		Yellow		
	Blue / Text		Blue		
	Text		Text		

