








































































Original	Replacement
 Source	 AV / Input / RDS
 Power	 Power
 Digital/Analog	 Setup / OPT /
 Tv/Radio	 TV/Radio /
 Sync Menu	 Menu / Home
 Exit	 Exit / Cancel / Clear
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 [i]/[?]	 Info / Angle
 0	 0

Original	Replacement
 [≡]/Text	 Text / Goto
 Google Play	 Display / Media
 Netflix	 Shift + Red / Netflix /
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Action Menu	 D.Menu / Top
 Tv	 Shift + 1
 Up	 Up
 Guide	 Guide / EPG / -/-
 Left	 Left
 OK	 OK
 Right	 Right
 Back	 Back / Return
 Down	 Down
 Home	 Shift + Menu / Home





Original	Replacement
 Discover	 Picture / Format
 Vol+	 Vol+
 Recall	 Fav / Marker / PC
 Prog+	 CH+ / Page+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Prog-	 CH- / Page-
 Audio	 Audio / Lang I/II
 <<	 << / Tune-
 Play	 Play / Slow
 >>	 >> / Tune+
 [...]	 Subtitle / EQ
 I<<	 I<< / Preset-
 Pause	 Pause / Step / Freeze
 >>I	 >>I / Preset+
 Help	 Sleep / Timer
 Rec	 Rec / Rec Mode

Original	Replacement
 Stop	 Stop / Hold
 Title List	 Smart / List

