






























Original	Replacement
 Power	 Power
 Open/Close	 Eject / Surround
 Up	 Up
 Preset/Album+	 CH+ / Page+
 I<<	 I<< / Preset-
 I<<	 Left
 Play/Pause	 Play / Slow
 Play/Pause	 Pause / Step / Freeze
 Play/Pause	 OK
 >>I	 >>I / Preset+
 >>I	 Right
 Preset/Album-	 CH- / Page-
 Down	 Down
 Mute	 Mute / Dimmer
 Disp	 Display / Media
 Stop	 Stop / Hold
 Menu	 Menu / Home





Original	Replacement
 Max	 Smart / List
 Vol-	 Vol-
 Vol+	 Vol+
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Prog/Clock Set	 TV/Radio /
 0	 0
 Repeat/Shuffle	 Green / APP / Repeat
 Repeat/Shuffle	 Blue / Prime Video / Random
 Sleep/Timer	 Sleep / Timer











Original	Replacement
 Power	 Power
 Open/Close	 Eject / Surround
 Up	 Up
 Preset/Album+	 CH+ / Page+
 I<<	 I<< / Preset-
 I<<	 Left
 Play/Pause	 Play / Slow
 Play/Pause	 Pause / Step / Freeze
 Play/Pause	 OK
 >>I	 >>I / Preset+
 >>I	 Right
 Preset/Album-	 CH- / Page-
 Down	 Down
 Disp	 Display / Media
 Mute	 Mute / Dimmer
 Stop	 Stop / Hold
 Menu	 Menu / Home

Original	Replacement
 Max	 Smart / List
 Vol-	 Vol-
 Vol+	 Vol+
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Prog/Clock Set	 TV/Radio /
 0	 0
 Repeat/Shuffle	 Green / APP / Repeat
 Repeat/Shuffle	 Blue / Prime Video / Random
 Sleep/Timer	 Sleep / Timer





































Original	Replacement	Original	Replacement
	DSC		Setup / OPT /
	DBB		D.Menu / Top





Original	Replacement
	 Power
	 Eject / Surround
	 Up
	 CH+ / Page+
	 I<< / Preset-
	 Left
	 Play / Slow
	 OK
	 Pause / Step / Freeze
	 >>I / Preset+
	 Right
	 CH- / Page-
	 Down
	 Display / Media
	 Mute / Dimmer
	 Stop / Hold
	 Menu / Home










Original	Replacement
	 Smart / List
	 Vol-
	 Vol+
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 TV/Radio /
	 0
	 Blue / Prime Video / Random
	 Green / APP / Repeat
	 Sleep / Timer







Original	Replacement
	 Power
	 Eject / Surround
	 Up
	 CH+ / Page+
	 I<< / Preset-
	 Left
	 Play / Slow
	 OK
	 Pause / Step / Freeze
	 >>I / Preset+
	 Right
	 CH- / Page-
	 Down
	 Display / Media
	 Mute / Dimmer
	 Stop / Hold
	 Menu / Home

Original	Replacement
	 Smart / List
	 Vol-
	 Vol+
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 TV/Radio /
	 0
	 Blue / Prime Video / Random
	 Green / APP / Repeat
	 Sleep / Timer





Original	Replacement
DSC	Setup / OPT /
DBB	D.Menu / Top

Original	Replacement

