

































































































Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Shift + Guide
	Recall		Back
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	P.Mode		Shift + Format
	S.Mode		Shift + Dual
	Aspect		3D
	TXT		Text
	Audio		Dual
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	PR+		Ch +
	PR-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Display		Info





Original	Replacement	Original	Replacement
 Sleep	 Sleep	 >>/PgDn	 >>
 Rec	 Rec	 <</PgUp	 <<
 Menu	 Menu	 Stop	 Stop
 Hold	 Options	 Play	 Play
 MIX	 Media	 Pause	 Pause
 Subpg.	 Shift + Subt	 Repeat	 Shift + Text
 Index	 Exit		
 Size	 Format		
 Reveal	 Smart		
 DTV/Radio	 TV/R		
 EPG	 Guide		
 FAV	 Pre Ch		
 List	 List		
 PVR Menu	 D. Menu		
 DTV Subt.	 Subt		
 I<<	 I<<		
 >>I	 >>I		

