







































































Original		Replacement		Original		Replacement	
	Power Tv		Power		Mute		Mute
	Power STB		Shift + Power		P+		Ch +
	Source		AV		P-		Ch -
	1		1		CH List		List
	2		2		Menu		Menu
	3		3		Smart Hub		Smart
	4		4		Guide		Guide
	5		5		Tools		Options
	6		6		Info		Info
	7		7		Return		Back
	8		8		Exit		Exit
	9		9		Up		Up
	0		0		Down		Down
	TTX/MIX		Text		Right		Right
	PRE-CH		Pre Ch		Left		Left
	Vol+		Vol +		Enter		Ok
	Vol-		Vol -		Red		Red





Original		Replacement		Original	Replacement
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	Search		TV/R		
	Status		Media		
	More		3D		
	E-Manual		D. Menu		
	Recommend		Format		
	AD/Subt		Subt		
	>>		>>		
	<<		<<		
	>>		>>		
	<<		<<		
	Pause		Pause		
	Rec		Rec		
	Play		Play		
	Stop		Stop		

