




































































































Original	Replacement	Original	Replacement
	Power		Power
	Sleep		Sleep
	TV		TV/R
	AV		AV
	Wide		Eject
	Scart	 +  Shift + AV	Shift + AV
	PC		Smart
	e		3D
	Menu		Menu
	Back		Back
	MPX		Options
	EPG		Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Mute		Mute
	Display		Info
	CH List		List
	([.])		Dual
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9





Original		Replacement		Original		Replacement	
	0		0				
	Recall		Pre Ch				
	Enter		Media				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Index		D. Menu				
	Subtitle		Subt				
	Subpage		Shift + Subt				
	Reveal		Exit				
	Size		Format				
	TTX/MIX		Text				
	Hold		Shift + TV/R				

