






















































































Original	Replacement	Original	Replacement
 Power	 Power	 8	 8
 Display	 Shift + Info	 9	 9
 DTV Menu	 Shift + Menu	 0	 0
 TV	 TV/R	 -/--	 Shift + Guide
 PC	 Smart	 PRE	 Back
 Line	 Media	 Vol+	 Vol +
 List	 List	 Vol-	 Vol -
 OPT	 Options	 Prog+	 Ch +
 EPG	 Guide	 Prog-	 Ch -
 i	 Info	 Red/M/S	 Red
 1	 1	 Green/Still	 Green
 2	 2	 Yellow/Sleep	 Yellow
 3	 3	 Blue/P.Size	 Blue
 4	 4	 Tv Menu	 Menu
 5	 5	 [≡x]/Exit	 Exit
 6	 6	 Mute	 Mute
 7	 7	 [≡]/TTX	 Text





Original	Replacement
 Up/P+	 Up
 Down/P-	 Down
 Right/Vol+	 Right
 Left/Vol-	 Left
 Enter	 Ok
 Open/Close	 Eject
 Setup	 Shift + D. Menu
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 <</<I Slow	 <<
 Slow I>/>>	 >>
 I<</<II Step	 I<<
 Step II>/>>I	 >>I
 Rec	 Rec
 Input	 AV
 PIP On/Off	 Shift + 3D

Original	Replacement
 PIP Sound	 Shift + Dual
 [=+]/Repeat	 Shift + Text
 [=i]/A-B	 Format
 [/≡]/Audio	 Dual
 [=o]/Subtitle	 Subt
 [=?]/Goto	 Pre Ch
 Title	 Sleep
 Angle	 Shift + Subt
 Menu	 D. Menu
 Zoom	 Shift + Eject
 Bookmark	 3D

