







































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	Source		AV
	Tv/AV		TV/R
	I/II		Dual
	Menu		Menu
	Exit		Exit
	*/SSM		Smart
	Stop		Stop
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	PR+		Ch +
	PR-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Swap		Pre Ch
	Auto		Guide
	[≡]/Text		Text
	Sleep		Sleep
	[≡M]/Mode		Options
	[≡x]/Update		Subt





Original		Replacement		Original	Replacement
	Blue/List		Blue		
	Yellow/Q.View		Yellow		
	Green/APC/PSM		Green		
	Red/PIP		Red		
	POP		Media		
	[≡i]/Index		Info		
	[≡o]/Time		List		
	[≡♦]/Size		Format		
	[≡+]/Hold		Eject		
	[.≡]/Mix		D. Menu		
	[≡?]/Reveal		3D		

