

















Original	Replacement	Original	Replacement
 Power	 Power	 Pause	 Pause
 Sleep	 Sleep	 Stop	 Stop
 Display	 Info	 Clear	 Exit
 Clock/Timer	 Format	 EQ	 Dual
 Clock/Timer Set	 3D	 Folder+	 Ch +
 Tuner Memory	 Back	 Folder-	 Ch -
 Play Mode/Tuning Mode	 Shift + Play	 Vol+	 Vol +
 Repeat FM	 Text	 Vol-	 Vol -
 USB	 Red	 Enter	 Ok
 CD	 Green		
 Band/Tuner	 Yellow		
 Function	 Blue		
 I<</-	 I<<		
 >>I/+	 >>I		
 <</+	 <<		
 >>/-	 >>		
 Play	 Play		

