






| Original | Replacement | Original | Replacement |
|--|---|--|---|
|  Power |  Power |  Vol- |  Vol- |
|  Text |  Text / Goto |  Exit |  Exit / Cancel / Clear |
|  Mute |  Mute / Dimmer |  Menu |  Menu / Home |
|  1 |  1 |  Back |  Back / Return |
|  2 |  2 |  Up |  Up |
|  3 |  3 |  Left |  Left |
|  4 |  4 |  OK |  OK |
|  5 |  5 |  Right |  Right |
|  6 |  6 |  Down |  Down |
|  7 |  7 |  Red |  Red / Netflix / Search |
|  8 |  8 |  Green |  Green / APP / Repeat |
|  9 |  9 |  Yellow |  Yellow / YouTube / Repeat |
|  CH+ |  CH+ / Page+ |  Blue |  Blue / Prime Video / Random |
|  0 |  0 |  SAT |  Shift + 0 |
|  Vol+ |  Vol+ |  EPG |  Guide / EPG / -/- |
|  CH- |  CH- / Page- |  List |  Smart / List |
|  Tv/R |  TV/ Radio / |  Audio |  Audio / Lang I/II |



