



Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	COMP		Smart
	HDMI		Media
	AV		AV
	TV		Shift + Media
	Source		Shift + AV
	Info		Info
	Menu		Menu
	Aspect		Format
	Still		Pause
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Audio		Dual
	TV / Radio		TV/R
	Sub		Subt
	Text		Text
	[≡?]		Shift + D. Menu
	[≡^v]		Play
	Mix		Options
	EPG		Guide
	Red / P.Mode		Red
	Green / S.Mode		Green
	Yellow / S.Effect		Yellow
	Blue / Stereo		Blue
	Vol +		Vol +
	Vol -		Vol -
	Back		Back
	CH +		Ch +
	CH -		Ch -





Original	Replacement	Original	Replacement
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Fav		Shift + Pre Ch
	Prev		Pre Ch
	PIP		D. Menu
	P.Source		Eject
	P.Size		3D
	Position		List
	P.Swap		Shift + Back

Original	Replacement	Original	Replacement
	Sleep		Sleep

