



Original	Replacement
Power	Power
Repeat	Text
A-B	+  Shift + Text
Open / Close	Eject
N / P	TV/R
Subtitle	Subt
Angle	Format
Language	Dual
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

Original	Replacement
0	0
10+	Guide
Time	AV
Setup	Options
Title	Media
Up	Up
Right	Right
Down	Down
Left	Left
Enter	Ok
PBC	Smart
Menu	Menu
Vol -	Vol -
Vol +	Vol +
Zoom	+  Shift + Eject
Return	Back
L / R	+  Shift + Dual





	Original	Replacement	
	 Step	 Shift + Pause	
	 Slow	 Shift + Play	
	 Clear	 Exit	
	 Program	 Sleep	
	 Mute	 Mute	
	 Display	 Info	
	 Prev  <<	  <<	
	 Next >>	 >>	
	 Rev <<	 <<	
	 Fwd >>	 >>	
	 Stop	 Stop	
	 Play / Pause	 Play	
	 Play / Pause	 Pause	
	 V-Mode	 3D	

	Original	Replacement

