





































Original	Replacement
 Power	 Power
 Open / Close	 Eject / Surround
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Step	 Pause / Step / Freeze
 0	 0
 3D	 Picture / Format
 S.Fit	 Text / Goto
 Zoom	 Zoom / Size
 Digest	 Sleep / Timer

Original	Replacement
 <<	 << / Tune-
 Stop	 Stop / Hold
 Play / Pause	 Play / Slow
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 Menu	 Menu / Home
 Return	 Back / Return
 Top Menu	 D.Menu / Top
 Up	 Up
 Display	 Display / Media
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 Clear	 Exit / Cancel / Clear
 Mode	 TV/Radio /





Original	Replacement	Original	Replacement
Bookmark	Fav / Marker / PC		
Angle	Info / Angle		
Subtitle	Subtitle / EQ		
Audio	Audio / Lang I/II		
Setup	Setup / OPT /		
I.Replay	AV / Input / RDS		
Repeat	Green / APP / Repeat		
Repeat A-B	Yellow / YouTube / Repeat		

