



Original	Replacement	Original	Replacement
 Power	 Power	 Remain	 Guide
 DVD	 Shift + 1	 Cancel	 Exit
 Tuner	 Shift + 2	 <<<	 <<<
 Aux	 Shift + 3	 Repeat	 Text
 USB	 Shift + 4	 Step	 Shift + Pause
 Open / Close	 Eject	 >>>	 >>>
 TV / Video	 TV/R	 I<<<	 I<<<
 1 / RDS Display	 1	 Stop	 Stop
 2	 2	 Play / Pause	 Play
 3 / TA	 3	 Play / Pause	 Pause
 4 / PTY -	 4	 >>>I	 >>>I
 5 / PTY Search	 5	 Volume +	 Vol +
 6 / PTY +	 6	 Volume -	 Vol -
 7	 7	 Mute	 Mute
 8	 8	 Tuning + / CH +	 Ch +
 9	 9	 Tuning - / CH -	 Ch -
 0 / Video Sel	 0	 Menu	 Menu



















































Original	Replacement	Original	Replacement
 Return	 Back	 Sound Edit	 Media
 Up	 Up	 NT/PAL / Ez View	 Options
 Right	 Right	 Slide Mode	 AV
 Down	 Down	 Sleep	 Sleep
 Left	 Left	 Digest	 D. Menu
 Enter	 Ok	 Dimmer	 Blue
 Info	 Info		
 Audio	 Dual		
 Subtitle	 Subt		
 Dolby PL II Mode	 Red		
 Mo/St / Slow	 Shift + Play		
 Dolby PL II Effect	 Green		
 DSP/EQ	 3D		
 Test Mode	 Smart		
 Zoom	 Shift + Eject		
 P.Scan / Tuner Memory	 Pre Ch		
 Logo	 Yellow		





Original		Replacement		Original		Replacement	
	Power		Power		Menu		Menu
	Source		AV		Return		Back
	1		1		Up		Up
	2		2		Right		Right
	3		3		Down		Down
	4		4		Left		Left
	5		5		Enter		Ok
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Vol+		Vol +				
	Vol-		Vol -				
	Mute		Mute				
	CH+		Ch +				
	CH-		Ch -				

