








































































































Original	Replacement	Original	Replacement
 Power	 Power	 1	 1
 Source	 AV	 2	 2
 YouTube	 Media	 3	 3
 Netflix	 Smart	 4	 4
 FPay	 Shift + Smart	 5	 5
 Rec	 Rec	 6	 6
 Play	 Play	 7	 7
 Pause	 Pause	 8	 8
 Stop	 Stop	 9	 9
 Lang.	 Dual	 0	 0
 <<	 <<	 TV	 TV/R
 >>	 >>	 Recall	 Pre Ch
 [≡]...	 Subt	 Menu	 Menu
 Red	 Red	 WWW	 Shift + Media
 Green	 Green	 Q.Menu	 D. Menu
 Yellow	 Yellow	 Vol+	 Vol +
 Blue	 Blue	 Vol-	 Vol -





Original		Replacement		Original	Replacement
	P+		Ch +		
	P-		Ch -		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		Ok		
	Back		Back		
	Exit		Exit		
	[-O-]		Format		
	i		Info		
	FAV		Shift + Pre Ch		
	Mute		Mute		
	Music/Picture/Mov		Options		
	*/O		3D		
	[≡]		Text		
	Guide		Guide		

