



	Original	Replacement		Original	Replacement
	Power		Power		Ch.List
	Source		AV		List
	1		1		Ch +
	2		2		Ch -
	3		3		Media.P
	4		4		Media
	5		5		Menu
	6		6		Menu
	7		7		Guide
	8		8		Options
	9		9		Up
	0		0		Right
	TTX/MIX		Text		Down
	PRE-CH		Pre Ch		Left
	Vol+		Vol +		Ok
	Vol-		Vol -		Back
	Mute		Mute		Exit
					Red
					Green





Original		Replacement		Original		Replacement	
	Yellow		Yellow				
	Blue		Blue				
	P.Mode	 + 	Shift + Format				
	Dual I/II		Dual				
	3D		3D				
	AD	 + 	Shift + Subt				
	P.Size		Format				
	Subt.		Subt				
	<<		<<				
	Pause		Pause				
	>>		>>				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

