



























Original	Replacement
 Power	 Power
 Sleep	 Sleep
 Input	 AV
 Sound	 Dual
 Aspect	 Format
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu
 Guide	 Guide

Original	Replacement
 i	 Info
 Back	 Back
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Vol +	 Vol +
 Vol -	 Vol -
 Mute	 Mute
 P +	 Ch +
 P -	 Ch -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Index	 Shift + Info





Original		Replacement		Original		Replacement	
	Reveal		3D				
	Size		Eject				
	Text		Text				
	Hold		Stop				
	[≡O]		TV/R				
	Subtitle		Subt				

