



Original	Replacement
 Power	 Power
 Mute	 Mute
 TV / AV	 AV
 ?	 Smart
 Lock	 List
 Text	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide

Original	Replacement
 QV	 Pre Ch
 Aspect	 Format
 Subcode	 Subt
 Mix	 Shift + Text
 Cancel	 Exit
 Red / Picture	 Red
 Red / Picture	 Shift + Format
 Green / Sleep	 Green
 Green / Sleep	 Sleep
 Yellow / Timer	 Yellow
 Yellow / Timer	 TV/R
 Blue / Sound	 Blue
 Blue / Sound	 Shift + Dual
 Reveal	 Info
 Hold	 Stop
 - S ←	 Dual
 - P ←	 Options





Original	Replacement	Original	Replacement
 Up / P +	 Ch +		
 Up / P +	 Up		
 Down / P -	 Ch -		
 Down / P -	 Down		
 Right / V +	 Right		
 Right / V +	 Vol +		
 Left / V -	 Left		
 Left / V -	 Vol -		
 Menu	 Menu		
 Menu	 Ok		

