



| Original | | Replacement | | Original | | Replacement | |
|---|--------|---|-------|---|----------|---|----------------|
|  | Power |  | Power |  | Display |  | Info |
|  | Mute |  | Mute |  | CH + |  | Ch + |
|  | 1 |  | 1 |  | CH - |  | Ch - |
|  | 2 |  | 2 |  | Up |  | Up |
|  | 3 |  | 3 |  | Left |  | Left |
|  | 4 |  | 4 |  | Enter |  | Ok |
|  | 5 |  | 5 |  | Right |  | Right |
|  | 6 |  | 6 |  | Down |  | Down |
|  | 7 |  | 7 |  | LCD Menu |  | Menu |
|  | 8 |  | 8 |  | Exit |  | Exit |
|  | 9 |  | 9 |  | Input |  | AV |
|  | 0 |  | 0 |  | PMode |  | Shift + Format |
|  | -/- |  | Guide |  | SMode |  | Shift + Dual |
|  | Recall |  | Back |  | Sleep |  | Sleep |
|  | Vol + |  | Vol + |  | Fav |  | Pre Ch |
|  | Vol - |  | Vol - |  | Fav - |  | Shift + Down |
|  | Nicam |  | Smart |  | Fav + |  | Shift + Up |





| | Original | Replacement | Original | Replacement |
|---|-------------------|--|----------|-------------|
|  | Aspect |  Format | | |
|  | Play/Pause / Text |  Play | | |
|  | Play/Pause / Text |  Pause | | |
|  | Play/Pause / Text |  Text | | |
|  | Stop / Hold |  Stop | | |
|  | Lang |  Dual | | |
|  | Subtitle |  Subt | | |
|  | >> / Index |  >> | | |
|  | << / Size |  << | | |
|  | >> / Reveal |  >> | | |
|  | << / Subpage |  << | | |
|  | Red |  Red | | |
|  | Green |  Green | | |
|  | Yellow |  Yellow | | |
|  | Blue |  Blue | | |
| | | | | |
| | | | | |

