







































































| Original | Replacement | Original | Replacement |
|---|---------------|---|--------------|
|  | Power |  | Power |
|  | Mute |  | Mute |
|  | SUB |  | Subt |
|  | TXT |  | Text |
|  | EPG |  | Guide |
|  | Language |  | Dual |
|  | Go To |  | Smart |
|  | Repeat |  | Shift + Text |
|  | Page + |  | Shift + Ch + |
|  | Page - |  | Shift + Ch - |
|  | Menu |  | Menu |
|  | Exit |  | Exit |
|  | Up / CH + |  | Up |
|  | Down / CH - |  | Down |
|  | Right / Vol + |  | Right |
|  | Left / Vol - |  | Left |
|  | OK |  | Ok |
|  | FAV |  | Pre Ch |
|  | TV / Radio |  | TV/R |
|  | Up / CH + |  | Ch + |
|  | Down / CH - |  | Ch - |
|  | Right / Vol + |  | Vol + |
|  | Left / Vol - |  | Vol - |
|  | Recall |  | Back |
|  | Info |  | Info |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |












































| Original | | Replacement | | Original | | Replacement | |
|---|--------------------|---|---------|----------|--|-------------|--|
|  | 0 |  | 0 | | | | |
|  | << |  | << | | | | |
|  | >> |  | >> | | | | |
|  | I<< |  | I<< | | | | |
|  | >>I |  | >>I | | | | |
|  | Play |  | Play | | | | |
|  | Pause / Time Shift |  | Pause | | | | |
|  | Stop |  | Stop | | | | |
|  | Rec |  | Rec | | | | |
|  | Red / PVR |  | Red | | | | |
|  | Green / V-Format |  | Green | | | | |
|  | Green / V-Format |  | Format | | | | |
|  | Yellow / Aspect |  | Yellow | | | | |
|  | Yellow / Aspect |  | Options | | | | |
|  | Blue / Timer |  | Blue | | | | |
|  | Blue / Timer |  | AV | | | | |





| Original | Replacement | Original | Replacement |
|---|---------------|---|----------------|
|  | Standby |  | Power |
|  | Sub-T |  | Subt |
|  | TTX |  | Text |
|  | Mute |  | Mute |
|  | EPG |  | Guide |
|  | Audio |  | Dual |
|  | GOTO |  | Shift + Guide |
|  | Repeat |  | Shift + Text |
|  | Page + |  | Shift + Up |
|  | Page - |  | Shift + Down |
|  | Menu |  | Menu |
|  | Exit |  | Exit |
|  | Up / CH + |  | Up |
|  | Up / CH + |  | Ch + |
|  | Down / CH - |  | Down |
|  | Down / CH - |  | Ch - |
|  | Right / Vol + |  | Right |
|  | Right / Vol + |  | Vol + |
|  | Left / Vol - |  | Left |
|  | Left / Vol - |  | Vol - |
|  | OK |  | Ok |
|  | FAV |  | Shift + Pre Ch |
|  | TV / Radio |  | TV/R |
|  | Recall |  | Pre Ch |
|  | Info |  | Info |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |





| Original | | Replacement | | Original | | Replacement | |
|---|-------------------|---|----------------|----------|--|-------------|--|
|  | 0 |  | 0 | | | | |
|  | << Rev |  | << | | | | |
|  | >> Fwd |  | >> | | | | |
|  | I<< Prev |  | I<< | | | | |
|  | >>I Next |  | >>I | | | | |
|  | Play |  | Play | | | | |
|  | Pause / Timeshift |  | Pause | | | | |
|  | Stop |  | Stop | | | | |
|  | Rec |  | Rec | | | | |
|  | Red / PVR |  | Red | | | | |
|  | Green / V-Format |  | Green | | | | |
|  | Green / V-Format |  | Format | | | | |
|  | Yellow / Aspect |  | Yellow | | | | |
|  | Yellow / Aspect |  | Shift + Format | | | | |
|  | Blue / Timer |  | Blue | | | | |
|  | Blue / Timer |  | AV | | | | |

