







































































Original	Replacement	Original	Replacement
 Power	 Power	 -/--	 Shift + Guide
 Mute	 Mute	 TV Menu	 Menu
 Source	 AV	 DVB Menu	 D. Menu
 PMode	 Format	 D.Exit	 Exit
 SMode	 Shift + Dual	 QV	 Pre Ch
 I/II	 Dual	 Call	 Back
 Sleep	 Sleep	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 V-	 Vol -
 6	 6	 V+	 Vol +
 7	 7	 P-	 Ch -
 8	 8	 P+	 Ch +
 9	 9	 Red	 Red
 0	 0	 Green	 Green





Original	Replacement
Yellow	Yellow
Blue	Blue
Subtitle	Subt
Size	3D
Hold	Stop
Reveal	Smart
TV / Text	Text
Index	Shift + Info
Cancel	Shift + Back
Mix	Shift + Text
Subpage	Shift + Subt
FAV	Shift + Pre Ch
Info	Info
Language	Options
TV / Radio	TV/R
EPG	Guide

Original	Replacement

