






































































	Original	Replacement		Original	Replacement
	Power		Power		♪ / S.Mode
	[i+]		Info		⦿ / P.Mode
	DTT/TV		TV/R		Vol+
	AV1		Shift + 1		Vol-
	AV2		Shift + 2		I/II
	AV3		Shift + 3		Mute
	AV4		Shift + 4		P+
	AV5		Shift + 5		P-
	RGB1		Shift + 7		1
	RGB2		Shift + 8		2
	Menu		Menu		3
	Back		Back		4
	Up		Up		5
	Down		Down		6
	Right		Right		7
	Left		Left		8
	OK		Ok		9
					Shift + Dual
					Shift + Format
					Vol +
					Vol -
					Dual
					Mute
					Ch +
					Ch -
					1
					2
					3
					4
					5
					6
					7
					8
					9

































Original		Replacement		Original		Replacement	
	0		0				
	2-4-12 / [ ]< >		3D				
	[ ]≡		Options				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	[ ]≡i		List				
	[ ]≡X		Smart				
	[...]/Slide Show		Subt				
	[ ]≡? / Rotate		Pre Ch				
	[ ]≡		Text				
	Swivel		Sleep				
	[ ]<>		Format				
	Photo		Media				













































	Original	Replacement	Original	Replacement
	Power			
	OK			
	Up			
	Down			
	Right			
	Left			
	Menu			
	Play			
	Stop			
	Pause			
	<<			
	>>			
	P+			
	P-			





Original		Replacement		Original		Replacement	
	Power		Power		8		8
	OK		Ok		9		9
	Up		Up		0		0
	Down		Down				
	Right		Right				
	Left		Left				
	P+		Ch +				
	P-		Ch -				
	Vol+		Vol +				
	Vol-		Vol -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				

