







































































Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 Mute	 Mute	 Menu	 Menu
 FAV	 Pre Ch	 Exit	 Exit
 Subtitle	 Subt	 Up	 Up
 Info	 Info	 Left	 Left
 TTX	 Text	 OK	 Ok
 Recall	 Back	 Right	 Right
 List	 List	 Down	 Down
 1	 1	 EPG	 Guide
 2	 2	 Timer	 AV
 3	 3	 Pg Dn	 Media
 4	 4	 Pg Up	 Smart
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 <<	 <<
 8	 8	 >>	 >>
 9	 9	 I<<	 I<<





	Original	Replacement	Original	Replacement
	>>I		>>I	
	CH+		Ch +	
	Ch-		Ch -	
	Play		Play	
	Pause		Pause	
	Stop		Stop	
	Audio		Dual	
	Rec		Rec	
	Sleep		Sleep	
	TV / Radio		TV/R	
	Aspect		Format	
	Red		Red	
	Green		Green	
	Yellow		Yellow	
	Blue		Blue	

