






































































Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall/Last View	 Pre Ch
 Radio/Tv	 TV/R
 CH/Page+	 Ch +
 CH/Page-	 Ch -
 Internet	 Smart
 Skype	 Media

Original	Replacement
 I<< Skip	 I<<
 Skip >>I	 >>I
 << Slow/Search	 <<
 Slow/Search >>	 >>
 Stop	 Stop
 Pause	 Pause
 Play	 Play
 i/Status	 Info
 X/Exit	 Exit
 Option	 Options
 Return	 Back
 Direct Navigator	 List
 Guide	 Guide
 Function Menu	 Menu
 Up	 Up
 Down	 Down
 Right	 Right





Original	Replacement
 Left	 Left
 OK	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Rec	 Rec
 Rec Mode	 Shift + Rec
 Text	 Text
 STTL	 Subt
 Prog/Check	 Sleep
 Chapter	 AV
 Time Slip	 Eject
 Audio	 Dual
 Drive Select	 D. Menu
 Del	 Shift + Exit
 Manual Skip -10s	 Format

Original	Replacement
 Manual Skip +60s	 3D
 Power Tv	 Shift + Power
 Av Input Tv	 Shift + AV
 Vol+ Tv	 Vol +
 Vol- Tv	 Vol -
 CH+ Tv	 Shift + Ch +
 CH- Tv	 Shift + Ch -

