








































































































































Original	Replacement	Original	Replacement
 On	 Power	 Level Down	 Shift + CH- /
 Standby	 Shift + Power	 Level Up	 Shift + CH+ /
 Return	 Back / Return	 I<<	 I<< / Preset-
 Setup	 Setup / OPT /	 Play	 Play / Slow
 CH+/Disc+	 CH+ / Page+	 >>I	 >>I / Preset+
 Up	 Up	 <<	 << / Tune-
 Vol+	 Vol+	 Stop	 Stop / Hold
 CH-/Disc-	 CH- / Page-	 >>	 >> / Tune+
 Left	 Left	 Rec / Random	 Blue / Prime Video / Random
 Enter	 OK	 Rec / Random	 Rec / Rec Mode
 Right	 Right	 Pause	 Pause / Step / Freeze
 Vol-	 Vol-	 Input Sel. DVD	 2
 Down	 Down	 Input Sel. CD	 3
 Audio Sel	 Audio / Lang I/II	 Input Sel. V1	 1
 CH Sel / Top Menu	 D.Menu / Top	 Input Sel. V2	 4
 Test / Menu	 Menu / Home	 Input Sel. TAP	 5
 Muting	 Mute / Dimmer	 Input Sel. TUN	 6



















Original	Replacement	Original	Replacement
 Sleep	 Sleep / Timer	 Play	 Play / Slow
 On	 Power	 >>	 >>  / Preset+
 Standby	 Shift + Power	 <<	 << / Tune-
 Return	 Back / Return	 Stop	 Stop / Hold
 Setup	 Setup / OPT /	 >>	 >> / Tune+
 Disc+	 CH+ / Page+	 Random	 Blue / Prime Video / Random
 Vol+	 Vol+	 Pause	 Pause / Step / Freeze
 Disc-	 CH- / Page-	 Eject	 Eject / Surround
 Vol-	 Vol-	 Input Sel. DVD	 Shift + 2
 Audio Sel /	 Audio / Lang I/II	 Input Sel. CD	 Shift + 3
 Audio Sel /	 AV / Input / RDS	 Input Sel. V1	 Shift + 1
 Top Menu	 D.Menu / Top	 Input Sel. V2	 Shift + 4
 Menu	 Menu / Home	 Input Sel. TAP	 Shift + 5
 Muting	 Mute / Dimmer	 Input Sel. TUN	 Shift + 6
 Angle	 Info / Angle	 Input Sel. V3	 Shift + 7
 Subtitle	 Subtitle / EQ	 Input Sel. V4	 Shift + 8
 I<<	 I<< / Preset-	 Input Sel. V5	 Shift + 9







Original		Replacement		Original		Replacement	
	On		Power		2		2
	Standby		Shift + Power		3		3
	Disc+		CH+ / Page+		4		4
	Vol+		Vol+		5		5
	Vol-		Vol-		6		6
	Muting		Mute / Dimmer		7		7
	Subtitle		Subtitle / EQ		8		8
	I<<		I<< / Preset-		9		9
	Play		Play / Slow		+10		Guide / EPG / -/-
	>>I		>>I / Preset+		0		0
	<<		<< / Tune-				
	Stop		Stop / Hold				
	>>		>> / Tune+				
	Random		Blue / Prime Video / Random				
	Pause		Pause / Step / Freeze				
	Eject		Eject / Surround				
	1		1				

