







































































Original	Replacement	Original	Replacement
 Power	 Power	 Menu	 Menu
 Red	 Red	 Vol+	 Vol +
 [o]	 Format	 Vol-	 Vol -
 Green	 Green	 Mute	 Mute
 Timer/List	 List	 PR+	 Ch +
 Info	 Info	 PR-	 Ch -
 Yellow	 Yellow	 1	 1
 [▲]	 Blue	 2	 2
 [▲]	 3D	 3	 3
 Text	 Smart	 4	 4
 Text	 Text	 5	 5
 Up	 Up	 6	 6
 Left	 Left	 7	 7
 OK	 Ok	 8	 8
 Right	 Right	 9	 9
 Down	 Down	 AV	 AV
 Exit	 Exit	 0/-/--	 0

