







































































Original		Replacement		Original		Replacement	
	Standby		Power		Tv/Radio		TV/R
	Source		AV		Vol+		Vol +
	1		1		Vol-		Vol -
	2		2		Mute		Mute
	3		3		CH+		Ch +
	4		4		CH-		Ch -
	5		5		Menu		Menu
	6		6		Exit		Exit
	7		7		Up		Up
	8		8		Left		Left
	9		9		Enter		Ok
	0		0		Right		Right
	Display		Info		Down		Down
	Recall		Back		TXT		Text
	Freeze		Shift + Pause		Play		Play
	P.Mode		Format		Pause		Pause
	S.Mode		Shift + Dual		Stop		Stop





Original		Replacement		Original	Replacement
	Mix/FAV List		Pre Ch		
	Size/Subtitle		Subt		
	Cancel/Audio		Dual		
	Zoom		Eject		
	<</Index		<<		
	>>/Hold		>>		
	I<</Reveal		I<<		
	>>I/Subpage		>>I		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		

