







































































Original		Replacement		Original		Replacement	
	Power		Power		Up		Up
	Open / Close		Exit		Left		Left
	Red / ·))		Dual		OK		Ok
	Red / ·))		Red		Right		Right
	Green / [...]		Green		Down		Down
	Green / [...]		Subt		Return		Back
	Yellow / Info		Yellow		Menu		Menu
	Yellow / Info		Info		>>		>>
	Blue / Guide		Blue		<<		<<
	Blue / Guide		Guide		1		1
	Purple / Angle		Format		2		2
	Zoom		Eject		3		3
	TV / DVD		TV/R		4		4
	Live		Smart		5		5
	Clear		Shift + Exit		6		6
	Again		Vol +		7		7
	Adv		Vol -		8		8



