










































Original		Replacement		Original		Replacement	
	Standby		Power		SP/LP		Format
	Timer		AV		P+		Ch +
	Monitor		Smart		P-		Ch -
	1		1		Record		Rec
	2		2		<<		<<
	3		3		Play		Play
	4		4		>>		>>
	5		5		>I/Index		>>I
	6		6		Stop		Stop
	7		7		>I</Still		3D
	8		8				
	9		9				
	0		0				
	Select		Ok				
	Clear		Exit				
	System		Menu				
	Tracking		Options				

