



































































Original	Replacement	Original	Replacement
 Power	 Power	 8	 8
 Subtitle	 Subt	 9	 9
 Guide	 Guide	 0	 0
 Freeze	 Pause	 ENT	 Back
 FAV.CH	 Pre Ch	 Jump	 Options
 Sleep	 Sleep	 Info	 Info
 Mute	 Mute	 Input	 AV
 I/II	 Dual	 CH+	 Ch +
 P.Size	 Shift + Format	 CH-	 Ch -
 [≡]/[≡]	 Text	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 Exit	 Exit
 3	 3	 Menu	 Menu
 4	 4	 OK	 Ok
 5	 5	 Up	 Up
 6	 6	 Down	 Down
 7	 7	 Right	 Right





Original	Replacement	Original	Replacement
 Left	 Left		
 S.Mode	 Shift + Dual		
 Red	 Red		
 P.Mode	 Format		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 [≡i]	 Smart		
 [≡?]	 TV/R		
 [≡♦]	 Eject		
 [≡+]	 Media		

