







































| Original     | Replacement   | Original   | Replacement  |
|--------------|---|------------|--|
| On/Off       |  Power   | Return     |  Back   |
| Audio Off    |  Mute  | OK Enter   |  Ok   |
| Slow Down    |  Ch -  | Progr.     |  Sleep  |
| Slow Up      |  Ch +  | Menu Right |  Right  |
| Stop         |  Stop  | Menu Down  |  Down   |
| Subt.        |  Subt  | Volume+    |  Vol +  |
| Auto/Track   |  +  Shift + Right     | Next       |  >>   |
| Rep/A-B      |  TV/R  | Volume-    |  Vol -  |
| Pause        |  Pause   | Top Menu   |  +  Shift + Menu |
| Title        |  List  | Prev.      |   <<  |
| Repeat/1/All |  Text  | 1          |  1  |
| Zoom         |  +  Shift + Eject | 2          |  2  |
| Menu         |  Menu  | 3          |  3  |
| DVD/TV       |  AV  | 4          |  4  |
| Menu Up      |  Up  | 5          |  5  |
| Display      |  +  Shift + Info  | 6          |  6  |
| Menu Left    |  Left  | 7          |  7  |



| Original | Replacement   | Original     | Replacement  |
|----------|---|--------------|--|
| 8        |  8   | Karaoke/Step |  +  Shift + Pause      |
| 9        |  9   | Setup        |  OPT Options  |
| +10      |  Guide   | Play/Back    |  +  Shift + Left       |
| 0        |  0   | Video        |  D.MENU D. Menu   |
| Mode     |  SMART Smart   | Timer        |  +  AV Shift + AV      |
| Remain   |  FORMAT Format   | Mark         |  Red  |
| C/CH     |  PRE-CH Pre Ch   | F.Forward    |  >>   |
| Np       |  +  LIST Shift + List | Open/Close   |  Eject  |
| Pbc      |  +  SUBT Shift + Subt | Audio        |  DUAL Dual  |
| R/L      |  +  DUAL Shift + Dual | Info         |  INFO Info  |
| Record   |  Rec  | Angle        |  +  Shift + Red      |
| Rewind   |  <<  | 3D           |  3D 3D  |
| Play     |  Play  | Lang         |  +  Shift + Green  |
| Game     |  Blue  | Random       |  +  Shift + Yellow |
| Resume   |  MEDIA Media   | Shuffle      |  +  Shift + Blue   |
| Digest   |  Yellow  |              |  |
| Dimmer   |  Green   |              |  |

