










































Original	Replacement
 Power	 Power
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Guide	 Guide
 Smart/Colors	 Shift + Smart
 Home	 Smart
 CH+	 Ch +
 CH-	 Ch -

Original	Replacement
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Menu	 Menu
 Info	 Info
 Back	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 left	 Left
 OK	 Ok
 Netflix	 Shift + Media
 Prime Video	 Format
 You Tube	 Media
 Google Play	 3D
 MTS	 Options





Original		Replacement	
	Text		Text
	Sub		Subt
	TV		TV/R
	Play		Play
	Pause		Pause
	<<		<<
	>>		>>
	Stop		Stop
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

Original		Replacement	

